

microSD card User Manual

⚠ WARNING

- Keep out of reach of small children.
- Do not disassemble or alter the card.
- Do not bend, apply strong force to, strike, or place heavy objects on the card.
- Discontinue use of the card if it gives off an abnormal sound or odor, excessive heat or smoke.

Instructions for use

Failing to follow the instructions below may lead to failure or malfunctioning of the card, or the destruction and deletion of data recorded on it.

- Format the card according to instructions of the camera you intend to use. Prior to formatting, back up any stored data onto another storage device. If you are using the card on different devices, formatting the card on each respective device is recommended. Further, note that formatting on a personal computer using its standard formatter may lead to failure to write/read data. If this happens, format the card again on the device you intend to use.
- Transfer any important data to other storage devices as back-up data. During extended or repeated use, the writing of, reading of, or deletion of data will be disabled. Car Mate shall not be held responsible for the destruction or loss of data, irrespective of its nature or cause of failure, or damage related to such destruction or loss of data.
- Keep the terminal portion of the card away from direct contact with fingers, metallic or similarly hard objects. Do not short-circuit the card, as doing so can cause static electricity that may in turn lead to the destruction or loss of data.
- Keep the card dry and away from moisture. Use and store the card only within its recommended operating environment, such as the specified temperature and humidity. Keep the card away from dust, static electricity, electrical noise, strong magnetic fields, corrosive chemicals or fumes, heat-generating objects, or explosives. Do not expose to open flames, or otherwise heat the card. Keep the terminal portion of the card clean.
- Do not turn off the formatting device or remove the card from such device while data is being written to the card, or data is being read from the card.

Disclaimer

- Car Mate shall not be held responsible for any damage arising from fire, earthquake, act of a third party, or other accidents, misuse by user, inadvertently or intentionally, or from use of the product under any other abnormal conditions.
- Car Mate shall not be held responsible for any damage, loss of profit, or any claim or action brought against it by any third party arising from use or failure of the product.
- In no event shall Car Mate be held responsible for any destruction or loss of data while using this product, irrespective of its cause, of its nature, or level of damage related to such destruction or loss of data. Car Mate will not retrieve, recover or restore any data recorded on our products.

Caution on waterproofing

- Should the card come into contact with moisture, wipe it off using a soft cloth.
- The waterproofing property of this product does not guarantee that the product functions in any and all circumstances.

Caution on transferring ownership or disposing of the card

- Please note, even formatting this product, or deleting data using a formatting device such as a personal computer, leaves a possibility of such data still remaining, or of having it recovered. You are also advised to dispose this product according to your local regulations.

Caution on import/export

- When importing or exporting this product, software or data you have written thereon, observe any and all applicable laws including "The U.S. Export Administration Regulations".